




MORRIS

W7448SDL



USER MANUAL

MINI BAR

Please read this manual carefully before use this product

Dear customer:

Thank you for buying this counter top fridge. To ensure that you get the best results from your new fridge, please take time to read through the simple instructions in this booklet.

Please ensure that the packing material is disposed of in accordance with the current environmental requirements.

As old refrigerator equipment may contain CFC's which will damage the ozone layer.

When disposing of any refrigerator equipment please contact your local waste disposal department for advice on safe disposal.

This appliance must be only used for its intended purpose.

1. GENERAL SAFETY INSTUCTIONS

For your own safety and for the proper utilisation of the appliance, read this manual carefully, including the warnings and recommendations, before installing the appliance and using it for the first time. In order to avoid damage to the appliance and/or personal injury, persons using the appliance should be fully familiar with its operation and safety functions. Keep these recommendations close to the appliance, for future reference, and ensure that the document is transferred with the appliance, if it is sold or in the case of moving. This will ensure optimum operation of the appliance.

To avoid any risk of injury, keep this manual. The manufacturer declines any liability whatsoever in the case of operating/handling errors concerning the appliance.

Safety of children and other vulnerable persons

- This appliance may be used by children aged 8 years and above, and by persons who are physically, sensorially or mentally handicapped, or who have not learned to use the appliance, providing they are supervised by a person familiar with the appliance and who is aware of the risks involved. Children should not be allowed to play with the appliance. User cleaning and servicing operations should not be carried out by children, unless they are more than 8 years old and are supervised.
- Keep all packaging out of the reach of children, as there is a risk of suffocation.
- If you decide to scrap the appliance, disconnect it from the wall socket, cut the connection cable (as close to the appliance as possible) and remove the door, in order to prevent children playing with it, with the resulting risk of electric shock or being trapped inside.
- If an appliance with a magnetic door seal is being replaced by another appliance with a latch on the door or on the seal, ensure that the latch is disabled before selling or scrapping the old appliance. This will prevent the appliance from being transformed into a trap for children.
- Keep the appliance and its power cable out of reach of children less than 8 years old.
- Children aged from 3 to 8 years are allowed to load and unload this

- appliance.
- Children should be supervised to ensure they do not play with the appliance.

General safety

CAUTION — This appliance is intended to be used in household and similar applications; such as kitchen staff in shop; offices and other working environments; bed and breakfast; farm houses and clients in hotels, motels and other residential environments; catering and other similar non-retail applications.

CAUTION — Never store inflammable substances, such as aerosols, inside the appliance, as they could leak or release fluids.

CAUTION — A damaged power cable should be immediately replaced by the manufacturer or by a qualified retailer, in order to avoid any risk of electric shock.

CAUTION — Keep the ventilation openings well open and ensure that air can circulate, especially if the appliance is recessed into a wall.

CAUTION — Do not damage the refrigerating circuit.

CAUTION — Do not use electrical appliances inside the compartment, unless they are tolerated by the manufacturer.

CAUTION — The refrigerating and insulating systems contain inflammable gases. When the appliance is scrapped, it should be deposited at an accredited collection centre. Do not expose the appliance to fire.

Refrigerating fluid

The refrigerating circuit in the appliance uses refrigerating isobutane (R600a), which is a highly inflammable natural gas and is therefore dangerous for the environment. When transporting or installing the appliance, ensure that no element of the refrigerating circuit is damaged. The refrigerating fluid (R600a) is inflammable.

Caution: Fire risk

If the refrigerating circuit is damaged:

- Avoid open flames or any source of combustion.
- Ensure that the room in which the appliance is installed is well ventilated.

It is dangerous to change the specification of the appliance in any way whatsoever.

Damage to the power cable may cause a short circuit and/or electric shock.

Electrical safety

- We decline any liability in respect of incidents caused by poor electrical installation.
- Do not extend the power cable. Do not use an extension cable, or adapter, or multi-way socket.
- Check that the wall socket is not damaged. A wall socket in poor condition may cause the appliance to overheat and explode.
- Check that the wall socket used for the appliance is properly accessible.
- Never pull on the main power cable.
- Ensure that the appliance is always electrically earthed.
- If the wall socket is loose, do not connect the cable, as there is a risk of electric

shock or fire.

- Do not use the appliance if the interior lighting cover is not installed.
- Disconnect the appliance before replacing the lighting bulb.
- The appliance operates on a single phase 220~240 V / 50 Hz power supply. The appliance must be connected to an earthed wall socket, in accordance with applicable recommendations.
- Do not attempt to replace a damaged power cable, contact your after-sales service.
- The power socket must be easily accessible but out of reach of children. In case of doubt, contact your installation technician.
- When positioning the appliance, ensure the supply cord is not trapped or damaged.

Daily utilisation

- Do not store inflammable substances or fluids inside the appliance. This would create a risk of explosion.
- Do not operate other electrical equipment inside the appliance (mixers, whirling rotor for ice cream, etc.).
- When disconnecting the appliance, grip the plug firmly and do not pull on the cable.
- Do not expose the appliance to direct sunlight.
- Keep the appliance away from candles, luminaires and open flames, in order to avoid fire risk.
- This appliance is only designed to store wines and drinks.
- The appliance is heavy. Be careful when moving it.
- If your appliance is equipped with castors, remember that these are only designed to facilitate minor movements. Do not move the appliance over long distances.
- Do not lean or climb on the appliance or its elements.
- In order to avoid falling objects and to prevent damage to the appliance, do not overload the compartments of the appliance.

To avoid contamination of food, please respect the following instructions:

- clean regularly surfaces that come in contact with food and accessible drainage systems.
- store raw meat and fish in suitable containers in the refrigerator, so that it is not in contact with or drip onto other food.

Caution! Cleaning and servicing

- Before carrying out servicing, switch off the power supply and disconnect the appliance.
- When cleaning the appliance, do not use metal objects, steam systems, volatile fluids, organic solvents or abrasive substances.
- Do not use sharp or pointed objects to remove ice. Use a plastic scraper.

Important information concerning installation!

- To ensure proper electrical connection, follow the recommendations given in the present manual.
- Unpack the appliance and visually check that it is not damaged. Do not connect a

damaged appliance. Inform your retailer or point of sale of any damage. In such a case, keep the packaging.

- It is recommended that the appliance be allowed to settle for at least 4 hours before connecting the electrical power supply, so that the compressor fluid feed is correct.
- Proper air circulation is necessary to avoid overheating. To ensure sufficient ventilation, observe the installation recommendations provided.
- In order to avoid fire risk, wherever possible, ensure that the appliance is not in contact with walls or with any hot element (compressor, condenser). Observe the installation recommendations.
- The appliance should not be placed close to radiators or cooking hot plates or gas rings.
- Check that electrical sockets remain accessible when the appliance is installed.

POWER SAVING

To limit the electricity consumption of your appliance:

- Install it in an appropriate place (see “Installing your appliance”).
- Leave the doors open as little time as possible.
- Do not put food that is still hot into the appliance.
- To ensure that the appliance operates properly, clean the condenser regularly (see “Routine servicing of your appliance”).
- Regularly inspect the door seals and ensure that they are still closing properly. If this is not the case, contact your after-sales service.

Trouble shooting

- **Any electrical work should be carried out by a qualified and skilled technician.**
- The appliance should be repaired by an accredited repair centre, using only manufacturer’s original spare parts.

The appliance is designed for home use only. The manufacturer declines any liability whatsoever in the case of another utilisation.



R600A

Safety instructions



Caution: The refrigerating units use isobutane (R600a), and should not be placed close to ignition sources (for example, electrical contacts that are exposed or open contacts that could be closed by the refrigerating fluid in the event of a leak). The refrigerating fluid type is specified on the power cabinet identification plate.



Caution: Do not damage the refrigerating circuit in the appliance.



Caution: Do not use electrical equipment in the compartments of the appliance, unless they are of the type recommended by the manufacturer.



Caution: Do not obstruct the ventilation grills on the appliance.



Caution: Do not store explosive substances, such as aerosol cans, containing an inflammable propellant in the appliance

This appliance meets the requirements of all applicable European directives and their amendments.

INSTALLATION

Sighting of the appliance


Place the fridge in a location with a firm base. In order to prevent vibration and noise, the fridge must be levelled by adjusting the front feet.

Choose a well ventilated location with no less than 10 cm clearance around the fridge. Site the fridge away from direct sunlight and heat sources such as an oven or boiler.

Push your device gently to its location until reaching the wall. Once the unit is in its place, you must have 50 mm of space above. If there is no space above, leave 25 mm below.

Do not place the unit on the power cord.

All parts that become hot can not be exposed.



Stabilization


The appliance must be stable. Otherwise there will be vibrations.

Put the device straight, the 2 adjustable feet must touch the ground.

Stabilize by adjusting the feet on the front of the unit.

This device is heavy. You should be careful when you move it.


For details on the appliance, refer to the rating plate on the back of the refrigerator.



WARNING

- 1) You must be careful that the voltage of the refrigerator is the same as the voltage of the network where you connect your device.
- 2) Water in the food may cause frost in your appliance. Excessive frost may cause malfunction. This is why it is good that you defrost your device manually. During defrosting, place a container below the evaporator to collect the water that is going to flow.
- 3) When the power cord is damaged, have it repaired by a qualified person
- 4) It is dangerous to change the characteristics of this appliance
- 5) When the unit is not used for a long time, it is best to turn it off.
- 6) Wait 5 minutes before you restart the appliance after power failure

USE OF THE APPLIANCE



1. Icebox
2. Temperature control
3. LED Light
4. Removable shelves
5. Bottle balconies

BEFORE USING YOUR REFRIGERATOR

- Remove the exterior and interior packing.
- Check to make sure you have all of the following parts:
 - 1 x Instruction manual
 - 1 x Removable shelves
 - 2 x Bottle balconies
- Before connecting the refrigerator to the power source, let it stand upright for approximately 5 hours. This will reduce the possibility of a malfunction in the cooling system from handling during transportation.
- Before connecting the refrigerator to the power source clean the interior surface with warm water using a soft cloth.

Temperature control

The fridge has only one control for regulating the temperature in the compartment. The temperature control is located on the upper right hand side of the compartment.

The first time you turn the unit on, set the temperature control to '6'.

The range of the temperature control is from position OFF to '6'. After 24 to 48 hours, adjust the temperature control to the setting that best suits your needs. The setting of '4' should be appropriate for home or office use

To turn the appliance off, turn the temperature control to OFF

NOTE

Turning the temperature control to OFF position stops the cooling cycle but does not shut off the power to the unit.

If the unit is unplugged, has lost power, or is turned off, you must wait 3 to 5 minutes before restarting the unit. If you attempt to restart before this time delay, the unit will not start

The Chiller compartment

This compartment is designed for production of ice cubes and short-term storage (3-4 days at most) of some commercially frozen foods.

The temperature in this compartment does not get cold enough to freeze food safely for long periods of time and works best when the food is already frozen.

By design, this chiller compartment is not a true freezer and may not keep ice cream frozen, or freeze items.

A colder setting may be used for these items, but other items in the refrigerator may also be affected.

The chiller door is susceptible to breaking due to excessive ice build up. This part is not covered under your warranty. Be sure to defrost when the ice reaches 6mm inch thick

Defrosting

Remove the mains plug from the wall socket, open the door and remove all the food to a cool place. Defrost using a plastic scraper, or let the temperature rise naturally until the frost melts. Then wipe away the remaining ice and water. After this, plug the freezer back into the mains supply

CLEANING YOUR FRIDGE

Before you start to clean your fridge remove the mains plug from the power supply.

Use lukewarm water and bicarbonate of soda

Clean with a cloth soaked in this solution and then dry with a soft cloth.

PROLONGED OFF PERIODS

If the fridge is not in use for a long period of time, proceed as follows:

Disconnect the fridge from the main supply by removing the plug from the wall socket.

Clean and dry the inside as instructed under the heading of cleaning the fridge.

Leave the door open to prevent any unpleasant smells from building up while the freezer is not in use.

BEFORE CALLING FOR SERVICE

Please check the following points:

The fridge is not working

- Check if the plug is inserted correctly into the wall socket
- Check if there is power to the wall socket by plugging in another appliance.
- Check the fuse in fridge plug.

The fridge is noisy when running

- Check if the fridge is level and it is not in contact with another appliance or kitchen furniture.

The fridge does not cool sufficiently

- If the door has been opened too often, or it has been left open for a while it will take time for the fridge to reach its set temperature.
- Check the airflow the rear of the fridge has not been reduced due to insufficient clearance.

The following characteristics should not be looked upon as a problem.

- **A gentle tricking sound caused by coolant flowing the pipe.**
- **Compressor operating at high temperature.**

PROBLEMS WITH YOUR UNIT?

You can solve many common unit problems easily, saving you the cost of a possible service call. Try the suggestions below to see if you can solve the problem before calling the servicer.

TROUBLESHOOTING GUIDE

PROBLEM	POSSIBLE CAUSE
Unit does not operate.	Not plugged in. The circuit breaker tripped or blown fuse. The temperature control is set at "OFF".
Compressor turns on and off frequently.	The room temperature is hotter than normal. A large amount of food has been added to the unit. The door is open too often. The door is not closed completely. The temperature control is not set correctly. The door gasket does not seal properly. The unit does not have the correct clearances.
Vibrations.	Check to assure that the unit is level.
The unit seems to make too much noise.	The rattling noise may come from the flow of the refrigerant, which is normal. As each cycle ends, you may hear gurgling sounds caused by the flow of refrigerant in your unit. Contraction and expansion of the inside walls may cause popping and crackling noises. The unit is not level.
The door will not close properly.	The unit is not level. The door is reversed and not properly installed. The gasket is dirty. The shelf or water drip tray are out of position.

NOTICE ABOUT RECYCLING



Your product is designed and manufactured with high quality materials and components which can be recycled and reused.

This symbol means that electrical and electronic equipment, at their end-of-life,

should be disposed of separately from your household waste. Please dispose of this equipment at your local community waste collection/ recycling centre.

In the European Union there are separate collection systems for used electrical and electronic products.

Please help us to conserve the environment we live in!

DECLARATION OF CONFORMITY

Herewith, we state that this product, complies with the requirements of below directives:

EMC-Directive: 14 / 30 / EU

Low Voltage Directive: 14/ 35 / EU

ErP Directive 09 / 125 / EC

CE Marking: 93 / 68 / EEC

RoHS Directive: 11 / 65 / EU & Delegated Directive (EU) 15 / 863

The detailed declaration of conformity can be found at

www.morris.gr



Importer:

Kalliopi Karyda & Co, LP

87A, 17th Noemvriou str, P.C. 55534

Thessaloniki – Greece

T: +302316006600 | F: +302316006650

EUROPEAN DATA SHEET
 according to the regulations (EU) N°1060/2010
FRIDGE

BRAND	MORRIS
COMMERCIAL REFERENCE	W7448SDL
POWER SUPPLY	220-240 V / 50 Hz
PRODUCT DIMENSIONS (W x D x H) mm	450 x 450 x 495
NET WEIGHT	13 kg
NET CAPACITY	43L
ENERGY EFFICIENCY CLASS	A++
ENERGY CONSUMPTION calculated on the basis of results obtained over 24 hours in standardized test conditions. Actual energy consumption depends on conditions of use and the location of the appliance.	80 kWh / year
LED LIGHT POWER	1.2W
NO FROST	DEFROST
CLIMATIC CLASS	N-ST This appliance is intended to be used at an ambient temperature between " 16 " [lowest temperature] °C and " 38" [highest temperature] °C
ACOUSTIC EMISSIONS IN AIR IN dB(A) RE 1 pW	38 dB(A)
INSTALLATION TYPE	Free standing



IMPORTER:

Kalliopi Karyda & Co, LP

87A, 17th November str.

55535, Pylea, Thessaloniki

Tel. 2316 006600

Fax. 2316 006650

www.morris.gr